



## Mounting Tips

### MZ-Pivot Gate

#### Hardware

Parts	Quantity	Parts	Quantity
A. Left Support Weldment .....	1	H. 3/4" Flat Washers .....	4
B. Pivot Weldments .....	2	I. 3/4" Nuts .....	2
C. Rail w/Toe Board Weldment .....	1	J. 3/8" Nuts .....	8
D. 2" Washers.....	2	K. 3/8" Flat Washers.....	16
E. Rail Weldment .....	1	L. 3/8" Hex Bolts .....	8
F. Right Support Weldment .....	1	M. Plastic Plugs.....	4
G. 3/4" Hex Bolts .....	2		



**Safety Note:** There must be OSHA-approved fall protection devices in use during the installation of this product! Assemble the unit away from the edge of the mezzanine. After assembly is complete, move the MZ-Pivot Gate to the edge as shown and anchor to the floor.

The right and left side Mounting Frames (1) are pre-assembled at the factory. Note that the pivot point is not centered on the Mount Frame. Distance "X" is greater than distance "Y". The gate section with the Toe Board (3) must be installed on the "X" side as shown.

#### Step 1:

Insert the gate section (2) into the receivers as shown and secure with the supplied hardware items J, K and L.

#### Step 2:

Repeat the same process for gate section (3).

#### Step 3:

Move the entire assembly to the edge of the mezzanine. The Toe Board should be on the same end as the edge of the mezzanine or platform.

#### Step 4:

Multiple slots are provided to secure the assembly to the floor. You must use a minimum of (4) 3/8" fasteners per side, for a total of 8 fasteners. The fasteners should penetrate through the surface and be secured on the bottom side with washers and nuts.

#### Step 5:

Adjustment bolts (4) can be used to increase or decrease friction to the desired tension required to open and close the gate.

**Suggested Tools:** 9/16" Socket and a 9/16" Wrench